II. INDEX

[NOTICE]

★ When you order spare parts, please never fail to order the parts listed in this Index after making sure of what is the spare parts you want.

★ For modified or added parts, please refer to the technical information issued by our technical department.

★ What the part No. means;

Ex.)


0 0 0 – 0 8 9 4 0 – 0 0 1
For classification of parts
Main number in part No.
Surfix No.
(In case of modification this number is changed.)

★ When you order spare parts, please never fail to inform us all of this part No. (the number of eleven figures).

Part No.	Part Name	Q'ty	Page	Remark
003-26306-100	Pickup Roller	2	4	
005-24114-003	Shaft Gear; Original Holder	1	46	
007-13424-109	Base Block; Paper Guide; Rcv.	2	26	
011-11711-115	Fulcrum Screw; Stripper	3	8	
011-12104-018	Seal Tape	1	16	A4, Legal
014-13110-102	Slide Guide; Paper Guide; Rcv.; A3	2	26	
014-13113-004	Slide Frame; Paper Guide; Rcv.; A3	2	26	
015-16231-200	PCB Cover; Drum	1	14	
017-11649-006	Gear; Elevator	1	4	
017-13258-004	De-electricity Brush; Suction	1	24	
017-55052-104	Wire Harness; Counter	1	48	
017-97300-108	Wire Harness; JS III	1	48	
019-11812-106	Lock Ring	2	4	
020-11118-308	Bracket; Counter	1	2	
020-11201-302	Intermediate Gear	1	8	
020-11203-100	Pressure Lever	1	8	
020-11207-203	Cam; Pressure Roller	1	8	B4
020-11209-109	Pressure Spring	1	8	B4
020-11210-107	Shaft; Intermediate Gear	1	8	
020-11214-200	Cam; Pressure Roller; A4	1	8	A4
020-11215-001	Pressure Spring; A4	1	8	A4, Legal
020-11216-202	Cam; Pressure Roller; L	1	8	Legal
020-11221-001	Pressure Roller	1	10	B4
020-11227-107	Pressure Roller Support	2	10	
020-11231-007	Pressure Balance Shaft	1	10	
020-11235-100	De-electricity Brush; P	1	10	
020-11236-408	Guide Cover; Pressure	1	10	
020-11238-109	Pressure Roller; A4	1	10	A4, Legal
020-11241-100	Shaft; Separator	1	22	
020-11242-106	Lever; Separator	1	20	
020-11243-200	Arm; Separator	1	20	
020-11248-007	Adj. Plate; Separator	1	20	
020-11251-008	Spring; Separator	2	20	
020-11252-004	Release Arm; Separator	1	22	
020-11254-104	Base Plate; Separator	1	20	
020-11258-100	Lever; Pressure Solenoid	1	8	
020-11259-203	Spring; Pressure Solenoid	1	8	
020-11260-007	Separator	1	22	
020-11261-100	Pressure Solenoid Base	1	8	
020-11264-002	Release Lever; Separator	1	22	
020-11265-009	Base Plate; Release Lever	1	22	
020-11266-102	Spring; Release Lever	1	22	
020-11267-109	Soundproofing Sheet A	1	2	
020-11268-008	Soundproofing Sheet B	1	2	
020-11302-001	Timing Roller	1	10	
020-11303-008	Guide Roller	1	10	
020-11304-004	Shaft; Guide Roller	1	10	
020-11305-000	Pressure Shaft; Guide Roller	1	10	
020-11306-007	Pressure Plate; Guide Roller	1	10	
020-11307-003	Support F; Guide Roller	1	10	
020-11308-000	Support R; Guide Roller	1	10	
020-11309-006	Load Spring	1	10	
020-11310-101	Timing Cam	1	8	

Part No.	Part Name	Q'ty	Page	Remark
020-11311-205	Sector Gear	1	8	
020-11312-104	Pin; Sector Gear	1	8	
020-11314-107	Timing Link Plate	1	8	
020-11315-200	Main Cam	1	8	
020-11316-100	Print Positioning Lever	1	8	
020-11319-303	Print Positioning Adj. Plate	1	8	
020-11323-203	Print Positioning Base Ass'y	1	8	
020-11326-008	Print Positioning Cam	1	8	
020-11329-007	Spring; Guide Roller	1	8	
020-11330-102	Spring; Sector Gear	1	8	
020-11332-300	Timing Lever	1	8	
020-11501-306	Paper-Feed Tray	1	6	
020-11502-108	Support Plate F; P.-F.-T.	1	6	
020-11513-002	Lever; P.-F.-T.	2	6	
020-11514-106	Link Plate A; P.-F.-T.	2	6	
020-11515-102	Link Plate B; P.-F.-T.	2	6	
020-11516-001	Link Plate Shaft; P.-F.-T.	2	6	
020-11520-009	L. O. Sheet	1	6	
020-11521-102	Support Plate R; P.-F.-T.	1	6	
020-11525-205	Side Guide F; P.-F.-T.	1	6	
020-11526-201	Side Guide R; P.-F.-T.	1	6	
020-11527-100	Feed Tray Cover	1	6	
020-11605-608	Side Frame F; Elevator	1	4	
020-11606-604	Side Frame R; Elevator	1	4	
020-11613-007	Bracket; Upper Limit Sensor	1	4	
020-11619-102	Spring; Elevator	2	4	
020-11628-004	Guide Plate; Elevator	2	4	
020-11707-109	Housing; Stripper	1	10	
020-11708-008	Spring; Stripper	1	10	
020-11709-004	Housing Bracket; Stripper	1	10	
020-11711-009	Stripper Pad	1	10	Hardness 70
020-11712-102	Base Plate; Stripper	1	10	
020-11721-004	Stripper Pad; Black	1	10	Hardness 90
020-11734-009	Adj. Plate; Stripper	1	10	
020-11741-102	Paper Sensor Cover (Upper)	1	10	
020-11751-000	Paper Sensor Cover	1	10	
020-11752-406	Guide Plate Ass'y	1	10	
020-11753-100	Pad; 12x12x12	1	10	
020-11806-000	Shaft; Scraper	1	4	
020-11811-100	Spring B; P.-F. Pressure Adj.	1	4	
020-11812-000	Spring A; P.-F. Pressure Adj.	1	4	
020-11813-006	Arm; P.-F. Pressure Adj.	1	4	
020-11814-100	P.-F. Pressure Adj. Lever	1	4	
020-11816-005	Support; Pickup Roller Shaft	1	4	
020-11817-206	Shaft; Pickup Roller	1	4	
020-11818-008	Holder Plate; Scraper	1	4	
020-11830-008	Bracket; P.-F. Pressure Adj.	1	4	
020-12104-408	Ink Blocking Sheet; B4	1	16	B4
020-12105-200	Ink Blocking Sheet; A4	1	16	A4, Legal
020-12111-102	Drum Body Support F	1	16	
020-12112-109	Drum Body Support R	1	16	
020-12113-008	Bearing Cap	1	16	
020-12115-205	Main Gear; Drum	1	16	

Part No.	Part Name	Q'ty	Page	Remark
020-12116-104	Compensator	1	16	
020-12117-003	Drum Lock Plate	1	16	
020-12119-006	Main Gear; Squeegee	1	16	
020-12121-302	Screen Ass'y	1	16	
020-12125-308	Screen Hanger Plate	1	16	
020-12126-002	Screw; Screen Hanger	4	16	
020-12127-203	Spring; Screen	2	16	
020-12128-005	Light Absorber Strip	1	16	
020-12129-052	Drum Body	1	16	B4
020-12130-069	Drum Body; A4	1	16	A4
020-12131-065	Drum Body; L	1	16	Legal
020-12201-101	Clamp Plate Base	1	16	
020-12201-207	Fan Base; Separation	1	22	
020-12205-204	Clamp Magnet	1	16	
020-12213-100	Clamp Base C	1	16	
020-12214-106	Master Projection Plate Ass'y	1	16	
020-12215-102	Damper C	2	16	
020-12220-106	Clamp Plate 2	1	16	
020-12375-100	Filter	1	12	
020-12416-000	Rear Frame; Drum	1	12	
020-12418-003	Bracket; Drawer Connector	1	12	
020-12420-202	Guide Pin	2	12	
020-12421-004	Reinforce Plate; Drum Front Frame	1	12	
020-12422-000	Drum Hook (R)	1	12	
020-12423-007	Drum Hook (L)	1	12	
020-12433-002	Bracket; Locking Plate; Drum	1	12	
020-12434-009	Shaft; Locking Plate; Drum	1	12	
020-12435-005	Spring; 6.95	2	12	
020-12438-209	Locking Plate; Drum	1	12	
020-12441-200	Drum Shaft Clamper	2	16	
020-12447-100	Shaft; Drum Grip	1	12	
020-12449-006	Sleeve 32	1	16	
020-12454-000	Spring; 6.5: Locking Plate; Drum	1	12	
020-12502-209	Shaft Joint; Drum	2	14	
020-12503-000	Main Frame; Drum	1	14	
020-12504-309	Support Shaft; Drum	1	14	
020-12508-002	Stopper; Ink Distributor	1	14	
020-12509-106	Front Plate; Squeegee	1	14	
020-12510-104	Rear Plate; Squeegee	1	14	
020-12512-000	Metal Fix Plate	2	14	
020-12513-006	Metal F; Drive Shaft	1	14	
020-12514-100	Metal R; Drive Shaft	1	14	
020-12515-408	Side Frame F; Squeegee	1	14	
020-12518-300	Side Frame R; Squeegee	1	14	
020-12521-300	Squeegee Roller	1	14	
020-12522-102	Doctor Roller	1	14	
020-12531-306	Drive Shaft; Squeegee	1	14	
020-12534-100	Block F; Squeegee	1	14	
020-12535-107	Block R; Squeegee	1	14	
020-12536-200	Ink Blocking Plate (Front)	1	14	
020-12537-207	Ink Blocking Plate (Back)	1	14	
020-12538-009	Adj. Plate; Doctor	1	14	
020-12540-003	Bracket; Drum PCB	1	14	

Part No.	Part Name	Q'ty	Page	Remark
020-12544-009	Adj. Boss; Squeegee	2	14	
020-12545-102	Adj. Boss Set Plate; Squeegee	2	14	
020-12549-000	Adj. Plate (Rear); Doctor	1	14	
020-12611-202	Rail; Drum	2	18	
020-12615-003	Drum Holder R	1	18	
020-12622-107	Bracket; A Pos. Sensor	1	8	
020-12625-009	Support Plate; Drum Safety SW	1	8	
020-12631-106	Drum Catch	2	18	
020-12635-004	Connector Bracket; Drum	1	42	
020-12638-003	Holder Set Plate	1	2	
020-12701-104	Cam Housing; Clamp	1	20	
020-12706-106	Open Arm; Clamp	1	20	
020-12707-102	Master Release Arm; Clamp	1	20	
020-12708-001	Shaft; Clamp Arm	1	20	
020-12711-002	Set Plate; Clamp Cam	1	20	
020-12713-102	Spring; Clamp Arm	2	20	
020-12722-004	Encoder Disc; Clamp	1	20	
020-12723-000	Bracket; Clamp Sensor	1	20	
020-12724-007	Gear Housing; Clamp	1	20	
020-12725-003	Bracket; Clamp Motor	1	20	
020-12727-103	Clamp Cam	1	20	
020-13101-208	Cover Plate; Suction	1	24	
020-13106-200	Base Frame; Suction	1	24	
020-13107-001	Suction Box	1	24	
020-13108-105	Belt Pulley; Suction	2	24	
020-13109-004	Face Cover; Suction	1	24	
020-13110-100	Idle Shaft; Suction	1	24	
020-13111-203	Drive Shaft; Suction	1	24	
020-13114-105	Fixing Pin	2	2	
020-13116-205	P.-E. Pulley; Suction	2	24	
020-13118-100	Under Stopper; Suction	1	24	
020-13302-106	Nozzle (Upper); Separation	1	22	
020-13303-005	Nozzle (Lower); Separation	1	22	
020-13401-104	Stopper; P.-Rcv.-T.	1	2	
020-13402-100	Lock Plate (F); P.-Rcv.-T.	2	2	
020-13403-107	Lock Plate (R); P.-Rcv.-T.	1	2	
020-13404-103	Slide Guide (F); P.-Rcv.-T.	1	2	
020-13405-100	Slide Guide (R); P.-Rcv.-T.	1	2	
020-13406-203	Guide Plate (F); P.-Rcv.-T.	1	26	
020-13407-200	Guide Plate (R); P.-Rcv.-T.	1	26	
020-13411-100	Link Plate; P.-Rcv.-T.	1	26	
020-13412-300	Receiving Tray Plate	1	26	
020-13413-200	Back Stop; P.-Rcv.-T.	1	26	
020-13414-109	Paper Guide; P.-Rcv.-T.	2	26	
020-13415-105	Slide Rail	1	26	
020-13418-104	Damper; Back Stop; P.-Rcv.-T.	1	26	
020-13419-100	Damper Sheet; P.-Rcv.-T.	1	26	
020-13450-008	Bracket; JS III	1	48	
020-14001-509	Main Frame; M.-Rmv.	1	40	
020-14004-001	Bracket; Comressing Motor	1	40	
020-14010-001	Pulley Shaft; M.-Rmv.	1	40	B4
020-14011-202	Stay A; M.-Rmv.	1	40	
020-14012-101	Stay B; M.-Rmv.	1	40	

Part No.	Part Name	Q'ty	Page	Remark
020-14016-000	Vertical Transport Roller (Up)	1	40	B4
020-14017-200	Shaft; Compressing Plate	1	40	
020-14018-207	Compressing Plate; M.-Rmv.	1	40	
020-14021-003	Bracket; Compressing Sensor	1	40	
020-14022-107	Lift Spring F; M.-Rmv.	1	38	
020-14023-103	Lift Spring R; M.-Rmv.	1	38	
020-14024-207	Compressing Spring F; M.-Rmv.	1	40	
020-14025-203	Compressing Spring R; M.-Rmv.	1	40	
020-14026-200	Actuator Disc; M.-Rmv.	1	40	
020-14027-001	Shaft; M.-Rmv. Lever	1	40	
020-14028-008	Hook Spring; M.-Rmv.	1	40	
020-14029-004	Hook F; M.-Rmv.	1	40	
020-14030-002	Hook R; M.-Rmv.	1	40	
020-14031-009	Bracket; Compressing Sensor	1	40	
020-14038-208	Transfer Pulley B (Upper); M.-Rmv.	1	40	
020-14040-202	Transfer Pulley A (Upper); M.-Rmv.	1	40	
020-14044-208	Transfer Pulley C (Upper); M.-Rmv.	1	40	
020-14048-408	Gear Cover F; M.-Rmv.	1	40	
020-14051-301	Gear Cover R; M.-Rmv.	1	40	
020-14054-300	Side Frame F; M.-Rmv.	1	38	
020-14058-306	Side Frame R; M.-Rmv.	1	38	
020-14060-203	Lift Arm; M.-Rmv.	2	38	
020-14065-000	Protection Plate R; M.-Rmv.	1	40	
020-14101-201	Disposal Box	1	38	
020-14108-206	Stay (Lower); M.-Rmv.	1	38	
020-14112-009	Spring; V.-Transport Roller	4	38	
020-14113-102	Holder; V-Transport Roller	1	38	B4
020-14114-206	Bracket F; V.-T.-Roller	1	38	
020-14115-202	Bracket R; V.-T.-Roller	1	38	
020-14116-004	Vertical Transport Roller (Down)	1	38	B4
020-14124-104	Lever; Disposal Box	1	38	
020-14125-100	Bracket; Box Lever	1	38	
020-14126-000	Shaft; Box Lever	1	38	
020-14127-006	Spring; Box Lever	1	38	
020-14131-208	Transfer Pulley A (Lower); M.-Rmv.	1	38	
020-14135-203	Transfer Pulley C (Lower); M.-Rmv.	1	38	
020-14137-206	Transfer Pulley B (Lower); M.-Rmv.	1	38	
020-14140-002	Master Removal Hook 2	2	38	
020-14201-001	Pulley Shaft; M.-Rmv.; A4	1	40	A4, Legal
020-14202-008	Vertical Transport Roller (Up); A4	1	40	A4, Legal
020-14203-101	Holder; V-Transport Roller;A4	1	38	A4, Legal
020-14204-000	Vertical Transport Roller (Down); A4	1	38	A4, Legal
020-14308-000	Frame Bracket F	1	2	
020-14309-007	Frame Bracket R	1	2	
020-14316-208	Bracket F; Safety SW	1	38	
020-14319-304	Bracket R; Safety SW	1	38	
020-14321-201	Lever; Safety SW	2	38	
020-14322-003	Set Plate; Safety SW	3	8,38	
020-14323-000	Spring F; Safty SW	1	38	
020-14324-103	Actuator; Safety SW	2	38	
020-14325-002	Spring R; Safety SW	1	38	
020-14506-309	Bracket; Master Removal Sensor	1	40	
020-14702-205	Base Cover; M.-Rmv.	1	38	

Part No.	Part Name	Q'ty	Page	Remark
020-14934-300	Gear 35	1	40	
020-15101-400	Side Frame F; M.-M.	1	34	
020-15107-505	Side Frame R; M.-M.	1	34	
020-15117-004	Master Guide Plate; B4	1	32	B4
020-15121-001	Bracket; Master End Sensor	1	32	
020-15123-004	Intermediate Gear	1	32	
020-15124-000	Write Roller; B4	1	32	B4
020-15128-308	Stocker Guide Plate (Upper)	1	34	
020-15129-207	Stocker Guide Plate (Lower)	1	34	
020-15131-406	Load Guide Plate	1	32	
020-15133-204	Load Guide Plate (Lower)	1	34	
020-15134-006	Load Roller (Lower)	1	34	
020-15135-207	Shaft; Stocker Guide	1	34	
020-15136-106	Spring; Load Guide	2	32	
020-15148-007	Load Roller (Upper)	1	34	
020-15164-002	Stay Shaft; M.-M.	1	34	
020-15192-006	Lock Lever; Master Guide	1	32	
020-15195-005	Spring; Lock Lever	1	32	
020-15196-206	Bracket; Solenoid	1	32	
020-15201-102	Sector Gear	1	34	
020-15202-206	Bracket; Cutter	1	36	B4
020-15203-300	Bracket Stay; Sensor	1	34	
020-15204-306	Bottom Stay; M.-M.	1	34	
020-15205-000	Master Stopper; M.-M.	1	34	
020-15208-000	Bracket; Sensor	1	34	
020-15209-006	Support Plate; Load Roller	1	34	
020-15213-003	Bracket; M.-M.	2	2	
020-15216-207	Holder R; Master Roll	1	32	
020-15217-106	Pressure Plate; Flange	2	28	
020-15218-102	Sensor Cover	1	32	
020-15219-109	Flange R; Master Roll	1	32	
020-15221-006	Master Guide Plate;A4	1	32	A4, Legal
020-15222-002	Write Roller; A4	1	32	A4, Legal
020-15223-106	Bracket; Cutter; A4	1	36	A4, Legal
020-15226-105	Bracket; Flange Pressure Plate	2	28	
020-15227-101	Holder F; Master Roll	1	32	
020-15228-108	Flange F; Master Roll	1	32	
020-15230-307	Load Guide Plate (Upper)	1	34	
020-15232-300	Cutter Guide (Lower)	1	36	
020-15233-403	Cutter Guide (Upper)	1	36	
020-15237-000	Damper A	2	34	
020-15239-207	Damper B	2	34	
020-15240-302	Sub. Bottom Stay; M.-M.	1	34	
020-15245-100	Cutter Rubber	2	36	
020-15246-009	Mylar Sheet; Load Roller	1	34	
020-15247-102	Guide Cover; M.-M.	1	32	
020-15248-001	Mylar Sheet; Write Roller	1	36	
020-15252-009	De-electricity Brush; L	2	32,34	
020-15255-008	Sheet; Pressure Plate; Flange	2	28	
020-15501-408	Upper Frame; ADF	1	30	
020-15508-100	Bracket; Stripper Pad Ass'y	1	30	
020-15510-008	Shading Sheet	1	30	
020-15515-204	Hook Plate; ADF	1	30	

Part No.	Part Name	Q'ty	Page	Remark
020-15516-103	Exit Roller (Upper); ADF	2	30	
020-15517-002	Plate Spring C; Exit Roller	1	30	
020-15518-602	Original Guide Base Plate	1	30	
020-15523-100	Stripper Roller; ADF	1	30	
020-15524-106	Side Frame (F); Scanner	1	28	
020-15530-009	Side Frame (R); Scanner	1	28	
020-15537-003	Gear Holder; Scanner	1	28	
020-15541-000	Friction Spring	1	28	
020-15545-006	Gear Stopper	1	30	
020-15553-203	Exit Roller; Scanner	1	28	
020-15554-102	Hook Plate; Scanner	1	28	
020-15555-001	Spring; Hook Plate	1	28	
020-15556-300	Cover Plate A; Scanner	1	28	
020-15557-209	Cover Plate B; Scanner	1	28	
020-15567-000	Support Stay; TPH	1	28	
020-15568-200	Pressure Stay; TPH	1	28	
020-15569-002	Pressure Plate; TPH	2	28	
020-15576-009	Shaft; Exit Roller	2	30	
020-15577-307	Plate Spring; Stripper Pressure; ADF	1	30	
020-15578-001	Roller; Stripper Pressure; ADF	2	30	
020-15580-006	Metal; ADF Stripper Roller	1	30	
020-15591-105	Guide Bracket; Wire Harness	1	28	
020-15702-101	Slide Rack; Original Holder	2	46	
020-15703-108	Cover Stay; Scanner	1	28	
020-15707-006	Spring A; TPH Pressure	1	30	
020-15711-003	Lift Arm (F); Master Holder	1	32	
020-15713-200	Lift Base (F); Master Holder	1	32	
020-15714-207	Lift Spring (F); Master Holder	1	32	
020-15716-005	Lift Arm (R); Master Holder	1	32	
020-15718-202	Lift Base (R); Master Holder	1	32	
020-15719-209	Lift Spring (R); Master Holder	1	32	
020-15721-300	Bracket; Sensor	1	28	
020-15722-102	Plate Spring S; Exit Roller	2	30	
020-15724-008	Rack Cover	1	46	
020-15725-004	Mylar Sheet; Original Feed	2	30	
020-15726-108	Arm; Original Pickup	1	30	
020-15727-104	Bracket; Original Pickup	1	30	
020-15731-101	Spring A; Original Pickup	1	30	
020-15732-108	Spring B; Original Pickup	1	30	
020-15733-104	Drive Plate; Original Pickup	1	30	
020-15737-100	Link Plate; Original Feed	1	28	
020-15742-200	Link Base Plate; Original Feed	1	28	
020-15745-102	Base Pad; Original Feed	1	30	
020-15746-206	Shaft; Original Stopper	1	30	
020-15750-203	Original Stopper; ADF	1	30	
020-15751-200	Spring; Original Stopper	1	30	
020-15753-105	Pickup Roller; ADF	1	30	
020-15757-100	Set Plate; Original Pickup	1	30	
020-15758-107	Lock Plate; TPH	2	28	
020-15759-103	Stripper Pad Ass'y; ADF	1	30	
020-15762-007	Mylar Sheet; Original Pickup	1	30	
020-15763-003	Mylar Sheet; Original Stripper	1	30	
020-15764-204	Exit Guide; Original Feed	1	30	

Part No.	Part Name	Q'ty	Page	Remark
020-15766-002	Spring C; TPH Pressure	2	28	
020-17113-200	Bracket B; Carrying Grasp	3	2	
020-17116-005	Bracket; Front Cover	1	2	
020-17117-206	Bracket A; Carrying Grasp	1	2,42	
020-17211-202	Bracket; Main PCB	1	42	
020-17214-104	Bracket (Lower); Main PCB	1	2	
020-17217-006	Fulcrum Bracket (Upper)	2	2	
020-17218-002	Bracket; Power SW	1	42	
020-17219-009	Bracket; Wire Harness	1	42	
020-17221-100	Cover Plate; Wire Harness	1	2	
020-17250-003	Bracket; Option PCB	1	42	
020-17251-000	Bracket; Card Counter	1	48	
020-17252-006	Option PCB Cover	1	42	
020-22401-001	Front Frame; Drum II	1	12	
020-22404-000	Grip; Drum II	1	12	
020-22405-007	Side Block II	2	12	
020-22407-000	Ink Suction Nozzle; f19	1	12	
020-22408-006	Junction Nozzle II	1	12	
020-22409-002	Bracket; Inking Nozzle	1	12	
020-22412-003	Cartridge Set SW Plate	1	12	
020-22413-000	Cartridge Holder	1	12	
020-22414-006	Cartridge Set SW Cover	1	12	
020-22415-002	Inking Hose f12 II	1	12	
020-22416-009	Inking Hose f10 II	1	12	
020-22417-005	Center Nozzle II	1	12	
020-22418-001	Bracket; Drum Set SW II	1	12	
020-22421-002	Base Plate; Cartridge Stopper	1	12	
020-22422-009	Arm; Cartridge Stopper	1	12	
020-22425-008	Link Plate; Cartridge Stopper	1	12	
020-22428-007	Pin A; Cartridge Stopper	2	12	
020-22429-003	Pin B; Cartridge Stopper	1	12	
020-22430-001	Fulcrum Shaft; Lever Link	1	12	
020-22431-008	Spring; Cartridge Stopper	1	12	
020-22432-004	Drum Inserting Block Pin	1	12	
020-22433-000	Pin; Drum Inserting Block Pin	1	12	
020-22434-007	Spring; Drum Inserting Block Pin	1	12	
020-22435-100	Connecting Bracket; Set Lever	1	12	
020-22438-002	Link Plate A	1	12	
020-22439-009	Link Plate B	1	12	
020-22441-003	Link Plate C	1	12	
020-22445-009	Releasing Spring; Inserting Block Pin	1	12	
020-22446-005	Spring; Set Lever	1	12	
020-22448-008	Cartridge Set Lever	1	12	
020-22451-106	Drum Cover II	1	12	
020-22452-005	Arm Cover; Cartridge Stopper	1	12	
020-22453-001	Roller; Link Plate C	1	12	
020-22454-105	Side Frame; Drum II	1	12	
020-22459-000	Ink Guard Sheet	1	12	
020-22480-009	Slider A	1	12	
020-22481-005	Slider B	1	12	
020-22484-004	Slider C	1	12	
020-22485-000	Plate Spring; Slider A	1	12	
020-22486-104	Holder Table; Ink Cartridge	1	12	

Part No.	Part Name	Q'ty	Page	Remark
020-22601-108	Drum Holder II	1	18	
020-24035-002	* Lever; M.-Rmv. II	1	40	
020-24701-002	Upper Cover II	1	46	
020-24703-005	Original Stopper II	1	46	
020-25191-008	Cover; M.-M. Unit II	1	46	
020-25583-003	Cover; ADF II	1	30	
020-25584-000	Original Tray II	1	46	
020-25590-000	ADF Cover II	1	46	
020-25700-000	Original Side Guide (F) II	1	46	
020-25701-006	Original Side Guide (R) II	1	46	
020-27101-006	Front Cover; CR	1	46	
020-27102-002	Back Cover II	1	46	
020-27111-109	Bracket; Keyboard (L)	1	2	
020-27112-008	Bracket; Keyboard (R)	1	2	
020-27114-000	Carrying Grasp	4	2	
020-27117-107	Drum Inserting Stopper	1	46	
020-27302-001	Panel Frame II	1	44	
020-27303-008	Sub-Panel Cover A	1	44	
020-27304-004	Sub-Panel Cover B	1	44	
020-27307-003	Reinforcement Plate; Panel	1	44	
020-27308-000	Holder Ball	1	44	
020-27309-006	Ball Support Spring	1	44	
020-27313-003	Panel Frame Ass'y; 1630 Pic.		44	1630 EP, UP, C
020-27314-000	Main Panel Sheet; 1630 Pic.	1	44	1630 EP, UP, C, 1610 EP
020-27315-006	Sub-Panel Sheet; 1630 Pic.	1	44	1630 EP, UP, C
020-27316-002	Panel Frame Ass'y; 1630		44	1630 AW, AN, EN
020-27317-009	Main Panel Sheet; 1630	1	44	1630 AW, AN, EN, 1610 AW, AS
020-27318-005	Sub-Panel Sheet; 1630	1	44	1630 AW, AN, EN
020-27319-001	Panel Frame Ass'y; 1600 Pic.		44	1600 C
020-27320-000	Main Panel Sheet; 1600 Pic.	1	44	1600 C
020-27321-006	Sub-Panel Sheet; 1600 Pic.	1	44	1600 C
020-27322-002	Panel Frame Ass'y; 1610 US		44	1610 UI
020-27323-009	Main Panel Sheet; 1610 US	1	44	1610 UI
020-27324-005	Sub-Panel Sheet; 1610 US	1	44	1610 UI
020-27325-001	Panel Frame Ass'y; 1610 Pic.		44	1610 EP
020-27326-008	Sub-Panel Sheet; 1610 Pic.	1	44	1630 EP, UP, C
020-27327-004	Panel Frame Ass'y; 1610		44	1610 AW
020-27328-000	Sub-Panel Sheet; 1610	1	44	1610 AW, AS
020-27329-007	Panel Frame Ass'y; 1620 Pic.		44	1620 C
020-27330-005	Main Panel Sheet; 1620 Pic.	1	44	1620 C
020-27331-001	Sub-Panel Sheet; 1620 Pic.	1	44	1620 C
020-51002-108	Power Supply PCB; S-100	1	42	100V
020-51006-308	Power Supply PCB; H-200	1	42	200V
020-51010-208	Option PCB	1	42	
020-51012-308	Inlet PCB II	1	42	
020-51013-304	Inlet PCB III	1	42	
020-51020-009	Main PCB	1	42	
020-51021-005	Panel PCB II	1	44	
020-51022-001	Cartridge Set SW PCB	1	12	
020-55001-009	Wire Harness; Image Scanner	1	28	
020-55005-004	Wire Harneess; I/F	1	48	
020-55018-203	Wire Harness; M.-Rmv.	1	40	
020-55019-005	Wire Harness; Suction	1	24	

Part No.	Part Name	Q'ty	Page	Remark
020-55023-304	Wire Harness; Safety SW	1	42	
020-55024-009	Wire Harness; Separation	1	22	
020-55025-501	Wire Harness; ADF	1	30	
020-55030-203	Wire Harness; Main-Power	1	42	1630AW, C, AN, EN, 1610AW, UI, AN, 1600C, 1620C
020-55032-400	Wire Harness; Write Pulse Motor	1	34	
020-55033-601	Wire Harness; M.-M.-Main	1	42	
020-55034-306	Wire Harness; CN4	1	42	
020-55035-400	Wire Harness; P.-F. II	1	4,6	
020-55036-406	Wire Harness; CN10	1	42	
020-55037-100	Wire Harness; CN5	1	42	
020-55038-107	Wire Harness J; Drum	1	42	
020-55039-103	Wire Harness I; M.-SW	1	34	
020-55040-101	Wire Harness II; M.-SW	1	38	
020-55041-108	Wire Harness; Drum Safety SW	1	8	
020-55042-104	Wire Harness IV; M.-SW	2	34,38	
020-55045-308	Wire Harness J; Sensor	1	34	
020-55046-002	Wire Harness; P.-F.-T.	1	6	
020-55047-106	Wire Harness; Drum PCB	1	14	
020-55051-103	Wire Harness; TPH-Power	1	30	
020-55056-105	Wire Harness; Main-Power II	1	42	1630EP, UP, 1610EP
020-55060-005	Wire Harness; TPH Signal III	1	30	
020-55062-105	Wire Harness; Drum II	1	12	
020-60004-008	Drum PCB	1	14	
020-60006-108	Master Sensor III	1	38	
020-60008-003	Original IN Sensor	1	30	
020-60013-104	Paper Sensor	1	10	
020-60014-259	Safety SW; M.-M.		34	
020-60015-255	Safety SW; M.-Rmv.		38	
020-60016-251	Drum Safety SW		8	
020-60017-258	Cover Set SW; M.-Rmv.		38	
020-60020-259	Set SW; M.-M.		34	
020-60021-000	Master Removal Sensor	1	40	
020-60022-006	Original Det. Sensor	1	30	
020-65000-205	Pulse Motor	2	28,34	
020-65001-007	Fan	2	22,24	
020-65002-003	Solenoid	2	8,32	
020-65003-000	Clamp Motor	1	20	
020-65004-308	Vertical Transport Motor; M.-Rmv.	1	40	
020-65005-304	Compressing Motor; M.-Rmv.	1	40	
020-65006-009	P.-E. Motor; Suction	1	24	
020-65009-008	P.-F. Clutch	1	4	
020-65010-006	LD Clutch	1	32	
020-65011-002	Original Feed Solenoid	1	28	
020-65012-106	Inking Motor	1	12	
020-65013-005	Counter	1	44	
020-65014-001	Pulse Motor; N	1	8	
020-70002-607	Image Scanner; A4	1	28	A4, Legal
020-70003-506	Image Scanner; B4	1	28	B4
020-75000-009	Edging; EO-10N	1	42	
020-75001-005	Damper D	2	42	
020-80020-	System ROM; CRS	1	42	
020-91310-409	Unit/ Main Motor	1	8	
020-91610-003	Elevator Motor	1	4	

Part No.	Part Name	Q'ty	Page	Remark
020-92070-002	Unit/ Ink Pump II	1	12	
020-94100-057	Unit/ Master Removal; B4 II		38,40	B4
020-94200-051	Unit/ Master Removal; A4 II		38,40	A4, Legal
020-95010-108	Unit/ Cutter	1	36	
020-97012-507	Power Cord Ass'y 100V		42	100V
020-97013-503	Power Cord Ass'y 200V		42	200V
020-97015-000	Wire Harness J Ass'y; Drum		42	
020-97026-052	Unit/ Operation Panel; 1630 Pic.		44	1630 EP, UP, C
020-97027-059	Unit/ Operation Panel; 1630		44	1630 AW, AN, EN
020-97028-055	Unit/ Operation Panel; 1600 Pic.		44	1600 C
020-97029-051	Unit/ Operation Panel; 1610 US		44	1610 UI
020-97030-050	Unit/ Operation Panel; 1610 Pic.		44	1610 EP
020-97031-056	Unit/ Operation Panel; 1610		44	1610 AW, AS
020-97032-052	Unit/ Operation Panel; 1620 Pic.			1620 C
020-98001-053	Shaft; Elevator	1	4	
020-98002-050	Pressure Roller Shaft	1	10	
020-98003-056	Unit / Clamp		20	
020-98004-052	T-TPH Ass'y; B4		30	B4
020-98005-059	T-TPH Ass'y; A4 CR		30	A4, Legal
020-98009-259	Unit / Squeegee		14	
020-98010-052	Unit/ Clamp Plate		16	
020-98011-059	Ink Distributor	1	14	
443-02001-003	Micro-SW; AM50031C331	1	34	
443-02004-002	Micro SW; AM50039C331F1SW	2	38	
443-02011-009	Micro-SW; AM50031C431	2	8,34	
443-30005-006	Sensor; GP1A71A	8	4,8,20,32,34,40	
443-32001-008	Sensor S; GP2A20L	2	6,34	
443-32002-004	Sensor S; GP2A22K	1	22	
443-32004-007	Sensor S; GP1A71M1	2	12,28	
443-36000-006	Sensor R; RPI-811N	2	8,20	
485-00001-804	Fuse 8A 125V 5.2 ULTSC	1	42	
485-00002-401	Fuse 10A 125V 5.2 ULTSC	1	42	
485-00003-203	Fuse 3.15A 250V 5.2 SET	3	42	
485-00003-408	Fuse 3.15A 125V ULTSC	3	42	
485-00003-505	Fuse 1A 125V ULTSC	2	42	
485-01421-009	Fuse 1A 250V 5.2 ET	2	42	
485-02320-001	Fuse 4A 250V 5.2 SET	1	42	
485-02520-000	Fuse 6.3A 250V 5.2 ET	1	42	
488-90027-000	Ground Wire; TPH	1	30	
505-00050-800	KGPS-8PF PCB Spacer	1	42	
550-20118-104	Seal; TPH	1	28	
550-21014-000	Master Stopper Seal; M.-M.	1	34	
550-21169-004	Seal; Master Disposal	1	38	
550-21170-002	Seal; Master Disposal; Pic.	1	38	
550-21172-005	Seal; P.-Feed Pressure	1	38	
550-21173-001	Seal; P.-Feed Pressure; Pic.	1	38	
550-21175-101	Seal; Setting Master	1	32	
550-21176-108	Seal; Setting Master, Pic.	1	32	
550-21277-001	Seal; Stripper Pressure	1	10	
550-21623-007	Seal; Setting Cartridge; Pic.	1	12	
550-21626-006	Emblem; CR1630 EP	1	46	
550-21627-002	Emblem; CR1630 UP	1	46	
550-21628-009	Emblem; CR1630 AW	1	46	

Part No.	Part Name	Q'ty	Page	Remark
550-21629-005	Emblem; CR1630 AN	1	46	
550-21630-003	Emblem; CR1630 EN	1	46	
550-21631-000	Emblem; CR1630 C	1	46	
550-21632-006	Emblem; CR1600 C	1	46	
550-21633-002	Emblem; CR1610 UI	1	46	
550-21634-009	Emblem; CR1610 EP	1	46	
550-21635-005	Emblem; CR1610 AW	1	46	
550-21636-001	Emblem; CR1610 AS	1	46	
550-21675-007	Emblem; CR1620 C	1	46	
550-21670-005	Seal; Drum Inserting Caution	1	12	
600-20061-009	Bearing; 608ZZ	4	8,10	
600-50057-006	Bearing; FLAW678ZZA	2	24	
607-07001-006	Metal; S8x12x19	2	32	
607-11001-002	Metal; F4x6x2.2; 8x1	2	30	
607-13000-003	Metal; F6x10 / 9x4; 12x1.5	13	10,28,30,34,38,40	
607-13000-020	Metal; F6x10/ 9x4; 12x5	1	20	
607-15000-000	Metal; F8x13/12x5; 16x2	13	4,20,22,32,34,40	
607-16001-000	Metal; F10x15/14x6; 18x2	8	4,10	
607-16002-007	Metal; F10x14 / 12.8x12; 18x2	2	10	
607-17050-005	Metal; F14x20 / 17x6; 24x2	2	10	
610-00007-101	HG Damper; 2G50-C50	1	34	
611-92800-004	Pulley; P28S2M60 (STS)	1	28	
611-93500-004	Pulley; P35S2M80 (STS)	1	24	
612-00200-003	Gear; m0.5x24x6	1	30	
612-03104-005	Gear; m1.25x14x6	1	40	
612-03105-001	Gear; m1.25x14x3	1	38	
612-10200-109	Gear; m0.5x24x4	1	30	
612-10201-105	Gear; m0.5x20x4	1	30	
612-11100-000	Gear; m0.8x19x6	1	28	
612-11101-007	Gear; m0.8x18x11	2	34	
612-11102-003	Gear; m0.8x18x5	1	14	
612-11200-005	Gear; m0.8x29x8.5	1	4	
612-11201-001	Gear; m0.8x24x5.2	1	30	
612-11202-008	Gear; m0.8x28x9	2	28,34	
612-11300-000	Gear; m0.8x34x8.5	2	4	
612-11400-101	Gear; m0.8x42x6	1	32	
612-11401-000	Gear; m0.8x45x5	1	14	
612-12302-006	Gear; m1x34x5	1	40	
612-12303-002	Gear; m1x30x5	1	14	
612-12304-009	Gear; OWC; m1x30x5	1	14	
612-12305-005	Gear; m1x34x14	1	20	
612-12306-001	Gear; m1x32x4	1	12	
612-16200-003	Gear; m2x23x6	1	8	
612-80400-105	Gear; m0.5x40 + m1x16	2	20,40	
612-80700-001	Gear; m0.5x75 + m0.8x14	2	8,28	
612-81200-002	Gear; m0.8x28 + m0.8x15	1	28	
612-81201-009	Gear; m0.8x26 + m1x13	1	12	
612-82300-000	Gear; m1x36 + m1x16	2	20	
612-82301-007	Gear; m1x34 + m1x16	2	40	
612-82500-000	Gear; m1x50 + m1x16	2	40	
612-82501-006	Gear; m1x50 + m1x24	1	40	
612-82700-009	Gear; m1x74 + m2x30	1	8	
613-12100-001	Gear; m0.8x21 + 15S2M	1	28	

Part No.	Part Name	Q'ty	Page	Remark
621-01162-007	Belt; 20-S2M-116	1	24	
621-01864-001	Belt; 40-S2M-186	1	28	
621-02664-006	Belt; 40-S2M-266	1	32	
628-21520-008	Transfer Belt; ϕ2x152	12	38,40	
629-93810-202	Transfer Belt; 14x0.65x381	2	24	
635-10714-000	Screw; ϕ7x1.1; M4x4.4	1	10	
635-17423-000	Stepped Screw; ϕ4x2.2; M3x4	1	28	
635-17433-006	Step Screw; 4x3; M3x6	1	36	
635-17523-005	Stepped Screw; ϕ5x2; M3x3	5	12	
635-17613-004	Stepped Screw; ϕ6x1.8; M3x4	3	22,32	
635-17634-001	Stepped Screw; ϕ6x3; M4x4	2	14	
635-17824-005	Stepped Screw; ϕ8x2.3; M4x4.4	4	4,10	
638-90000-012	Washer; 18x10.4x0.4	1	10	
638-90804-103	Washer; 8.5x16x0.4	4	8	
640-60030-004	O Ring; P3-1.9	2	14	
640-60050-005	O Ring; P5-1.9	1	28	
640-60100-126	O Ring; P10A-2.4	2	12,14	
640-60150-000	O Ring; P15-2.4	1	12	
640-60180-006	O Ring; P18-2.4	2	14	
640-61550-001	O Ring; P155-2.4	2	16	
660-01002-008	Rubber Foot TK-3215	4	2	
660-05000-018	Magnet Catch SM50P	1	2	
665-02021-304	Clamp DKN-13	2	42	
665-02025-504	Wire Saddle; WS-4W	1	42	
665-02025-601	Wire Saddle; LWS-2N	1	42	
665-02032-004	Clamp; YMC-15-0	8	34	
665-02038-002	Edging Saddle; ESD-2	2	28	
665-02039-009	Edging Saddle; ESD-17L	2	28,42	
665-02043-006	Wire Saddle; LWS-1316	4	42	
665-02903-005	Power Band T14	2	12	
665-02906-004	Hose Band	2	12	
665-04016-006	Snap Bushing; SB-1000-12	1	34	
665-04032-001	Edging; EO-12N	1	42	
665-04037-003	Free Bushing; NJ-23	2	28	
X-530	Pin; ϕ2x14	2	4	
	The order for the above (X-530) numbered parts are available only by quantities of tens.			